

Key to wiring diagram model 200/8, 220/8 from May 1972 to August 1973

|    |                                               |    |                                              |    |                         |  |  |
|----|-----------------------------------------------|----|----------------------------------------------|----|-------------------------|--|--|
| 1  | Headlight unit, left                          | 11 | Cigar lighter                                | 33 | Trunk light             |  |  |
| a  | High beam                                     | 12 | Glove compartment light                      | 34 | Blower motor            |  |  |
| b  | Low beam                                      | 13 | Glove compartment light switch               | 35 | Fuel gauge sensor       |  |  |
| c  | Standing/parking light                        | 14 | Solenoid valve, automatic transmission       | 36 | Radio                   |  |  |
| d  | Turn signal light                             | 15 | Starter-lockout and back-up light switch     | 37 | Alternator              |  |  |
| e  | Fog light                                     | 16 | Signal system contact                        | 38 | Voltage regulator       |  |  |
| 2  | Headlight unit, left                          | 17 | Combination switch                           | 39 | Starter                 |  |  |
| a  | High beam                                     |    | a Turn signal light switch                   | 40 | Idle fuel cut-out valve |  |  |
| b  | Low beam                                      |    | b Passing light switch                       | 41 | Time delay switch       |  |  |
| c  | Standing/parking light                        |    | c Dimmer switch                              | 42 | Battery                 |  |  |
| d  | Turn signal light                             |    | d Wiper switch                               | 43 | Tail light unit, right  |  |  |
| e  | Fog light                                     |    | e Switch for wiping speed                    | a  | Turn signal light       |  |  |
| 3  | Brake fluid indicator light switch            |    |                                              | b  | Tail/parking light      |  |  |
| 4  | Brake light switch                            |    |                                              | c  | Back-up light           |  |  |
| 5  | Parking brake indicator light switch          |    |                                              | d  | Brake light             |  |  |
| 6  | Instrument cluster                            | 18 | Fuse box                                     | 44 | License plate light     |  |  |
| a  | Turn signal indicator light, left             | 19 | Carburetor heater, automatic starting device | 45 | Tail light unit, left   |  |  |
| b  | Turn signal indicator light, right            | 20 | Kick-down switch                             | a  | Turn signal light       |  |  |
| c  | Fuel reserve warning light                    | 21 | Door contact switch, front, left             | b  | Tail/parking light      |  |  |
| d  | Fuel gauge                                    | 22 | Front dome light w/switch                    | c  | Back-up light           |  |  |
| e  | Electric clock                                | 23 | Door contact switch, front, right            | d  | Brake light             |  |  |
| f  | Rheostat instrument lights                    | 24 | Rotary light switch                          |    |                         |  |  |
| g  | Instrument lights                             | 25 | Ignition starter switch                      |    |                         |  |  |
| h  | Charge indicator light                        | 26 | Blower switch                                |    |                         |  |  |
| i  | High beam indicator light                     | 27 | Pre-resistance, blower motor                 |    |                         |  |  |
| k  | Brake fluid and parking brake indicator light | 28 | Pre-resistance 1.8 $\Omega$                  |    |                         |  |  |
| 7  | Dual-tone horns (fanfares)                    | 29 | Ignition coil                                |    |                         |  |  |
| 8  | 4-way warning flasher switch/timer            | 30 | Distributor                                  |    |                         |  |  |
| 9  | Wiper motor with interval timer               | 31 | Spark plugs                                  |    |                         |  |  |
| 10 | Washer pump                                   | 32 | Plug connection, cable to rear components    |    |                         |  |  |

**Example:**

Wire designation 1.5 gr/rt

Basic color gr = grey

Identification color rt = red

Cross section of wire 1.5 = 1.5 mm<sup>2</sup>

Supplement 8. Extension May 1974. Service Manual Passenger Cars starting 1968  
Series 114-115

