ENGINE 601, 602, 603 (except, 602.98)

1	Vibration da	mper with	hub

(one-sectioned)

2 Central bolt 10.9

3 Conical piece

157 Hub

158 Dowel pin

159 Dished washers (3 in total, install

with convex face pointing to each

other)

160 Central bolt 8.8


161 Belt pulley

161a Belt pulley

162a Bolt

162b Bolt

163 Vibration damper



P03.30-0316-06


Modification notes

			,
1.6.95	Parallel key at front of crankshaft modified	see step 7	AR03.30-P-1600HW

MM	Removing, installing		
1.1	Remove radiator	Engine 601, 602 in model 124, 201 Engine 603 in model 124, 126, 140	AR20.20-P-3865HW
2	Remove poly V-belt		AR13.22-P-1202HW
3	Install retaining lock for crankshaft/starter ring gear		03-500
4,1	Remove crankshaft belt pulley (161)	Engine 601 in model 124, 201 1st version The crankshaft belt pulley is centered by the straight pin (158). Washers (162b) are placed below the hexagon socket bolts.	BA03.30-P-1002-01A
5.1	Remove crankshaft belt pulley (161a) and vibration damper (163), place washers (162b) below	i Engine 601 in model 124, 2nd version as of 10/85 and engine 602, 603 i The crankshaft belt pulley and the vibration damper are centered by the straight pin (158). Place washers (162) below bolts (162b).	BA03.30-P-1002-01A
6.1	Remove hub (157).	i Engine 601 in model 124 2nd version as of 10/85 and engine 602, 603 i Installation: Install dished washer (159) with convex face pointing toward bolt head.	BA03.30-P-1007-01A
		3	103 589 00 33 00

Flywheel, driven plate, vibration damper, starter ring gear

Number	Designation			Engine 601, 602, 603 with/without automatic transmission
BA03.30-P-1001-01A	Central bolt vibration damper strength class 8.8	1st stage	Nm	200
		2nd stage	پ	90
BA03.30-P-1002-01A	Bolt belt pulley/vibration damper to hub		Nm	25
BA03.30-P-1007-01A	Central bolt vibration damper strength class 10.9		Nm	320



Puller