Removal

- 1 Unclip sun roof headling at fron with sun roof 3/4 open (4 clips).
- 2 Completely open sun roof.
- 3 Pull out sun roof headling in forwad, upward direction.
- 4 Check upper halves of clips on sun roof headlining.
- 5 Check lower halves of clips on sun roof.

Installation

- 6 Close sun roof and set both sliding parts horizontally.
- 7 Completely open sun roof.









