




- 1 Right lighting unit
- 2 Left lighting unit
 - a Upper beam
 - b Lower beam
 - c Flash signal
 - d Parking light
 - e Fog light
 - f Clearance light
- 3 Instrument cluster
 - a Left signal indicator
 - b Right signal indicator
 - c Fuel reserve warning light
 - d Fuel level indicator
 - e Electric clock
 - f Control resistance for instrument lighting
 - g Instrument lighting
 - h Charging light
 - i Upper beam control
 - k Brake control
- 4 Two-tone horn system
- 5 Blower switch (air intake)
- 6 Blower motor (air intake)
- 7 Stop light switch
- 8 Reversing light switch
- 9 Foot pump windshield washer
- 10 Wiper motor
- 11 Control switch for brake fluid
- 12 Control switch for parking brake
- 13 Flash signal mechanism
- 14 Horn ring
- 15 Combination switch
 - a Flash signal switch
 - b Flash approach signal switch
 - c Hand dimmer
 - d Windshield wiper switch
 - e Wiper speed switch
- 16 Cigar lighter
- 17 Front left door contact
- 18 Reading light
- 19 Front right door contact
- 20 Fuses
- 21 Lead for optional extra (radio)
- 22 Battery
- 23 Starter
- 24 Rotary light switch
- 25 Steering lock
- 26 Glow starter switch
- 27 Glow plug resistance control
- 28 Glow plugs
- 29 Sleeve union for tail light wiring harness
- 30 Fuel level indicator
- 31 Generator
- 32 Voltage regulator
- 33 Trunk compartment light
- 34 Right tail light
 - a Flash signal
 - b Tail light
 - c Reversing light
 - d Clearance light
 - e Stop light
- 35 Left tail light
 - a Flash signal
 - b Tail light
 - c Reversing light
 - d Clearance light
 - e Stop light
- 36 License plate light



Models 200 D/8 and 220 D/8

