


30-1156 Removing and installing potentiometer of electronic accelerator pedal

Operation No. of operation texts and work units or standard texts
and flat rates:
30-1156



- | | |
|---|---|
| Plug connection of potentiometer | separate, expose, fit together. |
| Throttle control rods | detach, attach. |
| Return springs | detach, attach. |
| Fastening bolts for potentiometer (R25) | remove, insert. |
| Throttle control | check, adjust if necessary (see 30-1010). |