



K1

AR09.10-P-8221EB

Removing and installing intake scoop


14.7.94

ENGINE 119.97
in MODEL 129**Left intake scoop illustrated**

10 Intake scoop

B17/2 Intake air temperature sensor

Arrows Expanding clips



P09.10-0226-11

Fig. item, etc.	Work instructions		
B17/2	Coupling of intake air temperature sensor detach at left intake scoop		



Arrows	Expanding clips	remove	
--------	-----------------	--------	--