
ENGINE 601, 602, 603 (except, 602.982)



P05.20-0338-01

X	Removing, installing		
1	Remove cylinder head cover		
2	Remove injection nozzles	Naturally aspirated engine	07.1-230
		Turbo engine	07.1-6810
3.1	Remove viscous fan clutch	Engine 601 in model 202	AR20.40-P-5660HA
		Engine 601, 602 in model 124, 201 Engine 603 in model 124, 126, 140	AR20.40-P-5660HW
4.1	Remove fan	Engines with magnetic fan clutch	20-330
5	Attach dial gage holder to inlet valve of cylinder 1 and mount dial gage on valve tappet with prestress of 3 mm	S	363 589 02 21 00
		3	001 589 53 21 00
4	Inspecting		
6	Rotate engine in direction of rotation until a valve lift of 2 mm is indicated	Engine must not be rotated at the camshaft. Do not crank engine back during the measurement otherwise errors will occur.	BE05.20-P-1001-02C
		In this position, the marking on the vibration damper, see table (inlet valve opens after TDC), should be aligned with the TDC pointer on the timing case cover. If a difference of more than 4° CRA exists, replace the timing chain. ↓	
		Replacing timing chain	AR05.10-P-7601HX AR05.10-P-7601HX
		Camshaft marking	AH05.20-P-6992-03HB AR05.20-P- 6015HW/2
		Camshaft code number	BE05.20-P-1001-01C

Camshaft code numbers


Number	Designation	Engine 601.911/912/921 up to 10/84	Engine 601.911/912/921 as of 11/84 up to 10/88	Engine 601.911/912/921 as of 11/88	Engine 601.913
BE05.20-P-1001-01C	Camshaft code numbers	05	06	10	13


Camshaft code numbers

Number	Designation	Engine 602.911/ 912/961/962, 603 bis 10/88	Engine 602.911/ 912/961/962, 603 as of 11/88
BE05.20-P-1001-01C	Camshaft code numbers	07	11

Test data of valve timing

Number	Designation	 -			Engine 601 except 601.913, 602 except 602.982, 603	Engine 601.913
BE05.20-P-1001-02C	Timing inlet valve/exhaust valve at 2 mm valve lift and used timing chain	Inlet valve	opens after TDC	°CRA	12	12
		Inlet valve	closes after BDC	°CRA	17	12
		Exhaust valve	opens before BDC	°CRA	28	21
				°CRA	15	20
		Exhaust valve	closes before TDC			






Dial gage holder

Dial gage

AH05.20-P-6992-03HB	Camshaft, code numbers and allocation	i

Camshaft code numbers

The code number is stamped on the flange next to the TDC notch (arrow).



P05.20-0341-01