
77-130 Removal and installation of gasket and holding rails on sun roof opening



C
r
þ
r
U
r
ι
ţ

open, do not remove
mark on roof cutout at joins (arrows)
pull out of holding rails 2, 3, 4 and 5
remove and install (77–250)
unscrew 6 ea., screw in
remove and install (refer to installation note)
unscrew 8 ea., screw in
push toward the rear and remove in upward
direction

Holding rail (5)	can be removed and installed only upon removal of sun roof frame and drilling out of rivets (11
	each)
Gasket (9)	push into holding rails 2, 3, 4 and 5. The serrations on plug-in profile should point in
	upward direction.

Installation note

To make sure that the gasket (1) obtains an adequate hold in holding rails 2, 3 and 4, a gap dimension of 3 mm between holding rail and roof panelling should be maintained.